

# Z-Wave

## On this page:

- [Adding and Removing Z-Wave Devices](#)
- [Adding a Z-Wave Controller](#)
- [Displaying Status of Two Sensors with One Icon \(HS3\)](#)
- [Importing Z-Wave Devices](#)
- [Helpful Resources](#)

## Adding and Removing Z-Wave Devices

Information on adding and removing a Z-Wave device via the Z-Wave core legacy menu.

## Adding a Z-Wave Controller

In order to control Z-Wave devices, such as light switches, thermostats, door locks and sensors, they must be included into a Z-Wave "network". Follow the steps below to add your Z-Wave controller and create a Z-Wave network.

## Displaying Status of Two Sensors with One Icon (HS3)

How-to display status of two sensors with one icon in HS3. Note: This will work in HS4 but the steps included graphics are inaccurate.

## Importing Z-Wave Devices

Importing devices is only necessary if you are using the Aeon Labs Z-Stick to configure your Z-Wave network, otherwise that step can be skipped. You'll need to import that network into your HomeTroller, so that your devices can be monitored and controlled.

## Helpful Resources